

# LENS REPAIR KIT INSTRUCTIONS

CAUTION!! WEAR EYE PROTECTION WHILE FOLLOWING THESE INSTRUCTIONS!

1. Carefully scrape off sealant from around retaining ring using small knife or chisel.
2. Gently lift one side of the ring with a screwdriver and remove it.
3. If necessary, break lens close to the edge so it can be lifted out. CAUTION: Stay away from the vials as they are very sensitive and shouldn't be touched.
4. Scrape out any remaining sealant that still might be on the ledge that the lens must rest on. Try not to scratch the paint.
5. Before installing the new lens, blow out any dust or glass chips.
6. Clean and install lens. If a tight fit, it may be trimmed with glass trimmers or the edge carefully sanded down.
7. Apply a small bead of clear silicone (not included) around the edge of the lens.
8. Install retainer ring over caulk bed. (Trim the ring ahead of time if needed to fit your level properly.)
9. Gently press retainer ring down with a flat object, making sure the ring is seated evenly all around.
10. Wipe off any excess caulk before it sets up.
11. Finally, last but not least, apply a light coat of RAW LINSEED OIL to your level. This helps to protect and preserve your level. You may also use TUNG or LEMON OIL.

Thank You,

SMITH LEVEL CO.  
1703 Johnson Industrial Dr.  
EXCELSIOR SPRINGS, MO 64024  
**(816) 630-0070**